

User Manual

Pressure • Temperature • Humidity • Air Velocity • Air Flow • Acoustics

Thermo-hygrometers HD 100 - HD 150

[Kimo HD 100 Thermo-Hygrometer](#)
[Kimo HD 150 Thermo Hygrometer](#)



"Select" key
See table
"Functions available from main screen"

"Function" key

- 1x : "Hold" : measure holding
- 2x : "Min/Max" : display of minimum and maximum values from **channel 1** since last request.
- 3x : "Min/Max" : display of minimum and maximum values from **channel 2** since last request.
- 4x : **Back** to held measure.

"On / off" key

- ON : Switch-on
- OFF : Switch-off
- Escape : Return to previous screen

"Backlight" key

- 1x Level 1
- 2x Level 2
- 3x No backlight

"OK" key

- 1x "To validate"
or "To scroll down parameters"
see P2.

Functions available from main screen

Select parameters	%RH °C	→	(OK)	→	°C °C _{td}	→	(OK)	→	°C _{td} %RH
Select temperature units	1x	(Select)	→	(OK)	→	Press on	(Select)	key to scroll down units	⇒ Validate with (OK) key
Automatic shut-off	2x	(Select)	→	(OK)	→	Press on	(Select)	key to scroll down minutes	⇒ Validate with (OK) key
Beep	3x	(Select)	→	(OK)	→	Press on	(Select)	to activate or deactivate	⇒ Validate with (OK) key

■ **How to change battery**

1. Remove the front part at the back of the instrument
2. Remove old battery
3. Insert the new battery in accordance with proper polarity drew inside the housing.
4. Replace the front.

